


Pool Safety Requirements Before installing a fence, check with your local Council regarding specific pool fence requirements.

For further information visit **thearchitectschoice**.com.au



- 1. Mark the line of your fence using a string line.
- 2. Measure and mark the placement of your mini-posts refer to the mini-post spacing guide for positioning.
- 3 Use post packers to level and align mini-posts, then fix in place using appropriate fixings through corners of base plate and fit cover plates if required.
- 4. Loosen the 2 grub screws in side of mini-posts, then using a 2 man lift, insert the glass panels into the mini-post, ensuring the stainless plate and rubber inserts are in the correct position. Check the glass spacing between panel is correct then tighten the grub screws.
- 5 Check the glass is level and plumb. If required, an assortment of packers and spacers are provided to level the glass panels, simply loosen the grub screws to make any adjustments then retighten.

Mini-post Spacing Guide				
Panel width	Mini-post centre #	Panel width	Mini-post centre #	
1300	217mm	800	133mm	
1200	200mm	700	117mm	
1100	183mm	600	100mm	
1000	167mm	500	83mm	
900	150mm			

Accessories

Friction Fit Handrail and Handrail joiners (polished stainless steel or black)
Friction Fit Clamps – Add rigidity to top of panels, straight corner and adjustable angles available.

Suitable for residential applications where the fall is less than 1 metre to ground level: for heights above 1 metre seek independent engineering advice and consult with your local building authority to determine suitability prior to installation. Suitable for external use only.











Warranty Information

Limited Manufacturer's Warranty for Protector Premium Stainless Steel and Aluminium.

Our Goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Warranty

The Supplier warrants that the Product is free from defects in workmanship and materials for the Warranty Period.

What the Supplier must do if the Product is Defective Subject to the conditions of warranty set out in clause 3, if the Product is found to be defective and is returned to the place of purchase at the purchaser's expense during the Warranty Period, the Supplier will repair or replace the Product free of charge.

What the Purchaser must do to Claim Under the Warranty In order to claim under the Warranty, the purchaser must:

- 3.1 Be able to show that the damage or defect has arisen solely from faulty materials or manufacture;
- 3.2 Be able to show that the Product has not been misused, mistreated, damaged or neglected by physical means including but not limited to fair wear and tear, accidents or act of God after purchase;
- 3.3 Be able to show that it has fulfilled its Product Maintenance Obligations;
- 3.4 Be able to show that the Product has not been used in a manner inconsistent with the Prescribed Purpose;
- 3.5 Be able to show that the Product has not at any time been:
 - a. attached to; nor
 - b. fixed to: nor
 - c. installed such that it is touching;

Any other metallic objects or materials which are not steel;

- 3.6 Be able to show that the Product was inspected and accepted within forty eight (48) hours of the purchase;
- 3.7 Be able to show that harsh abrasives including but not limited to hydrochloric acid have never come into contact with the Product;
- 3.8 Be able to show that It was the original purchaser by production of the original receipt of purchase clearly showing the Date of Purchase;
- 3.9 Pay all transportation charges incurred in returning defective Product (or parts thereof) for repair, together with the cost of returning them to the purchaser.

Other Important Information in Relation to the Warranty

- 4.1 The Liability of the Supplier pursuant to this Warranty is (to the extent it is lawful to do so) limited to the cost of repair or replacement of the Product. The Supplier shall not in any circumstances be liable for physical or financial injury, loss or damage or for consequential loss or damage of any kind arising from the Product or its use or application by the purchaser.
- 4.2 This Warranty is non-transferable and does not apply to any purchaser who bought the product from a reseller or distributor not authorised by the Supplier, including but not limited to purchases from internet auction sites.
- 4.3 Should the Product prove to be irreparable, the Supplier reserves the right to substitute an equivalent product if available or to retract the Warranty if no replacement is available.
- 4.4 The benefits provided to the purchaser by the Warranty are in addition to other rights and remedies available to the purchaser

Who is Giving the Warranty?

The entity giving the Warranty is: Protector Premium ACN 619 190 797

2a Page Street Kunda Park QLD 4556 Phone: 03 8595 3713

Email: sales@protectorpremium.com.au

Definitions

"the Date of Purchase" means the date the Product is purchased as evidenced by the properly dated receipt issued to the purchaser at the time of purchase.

"Product Maintenance Obligations" means washing down the Product with clean fresh warm water containing a mild detergent (non-acidic and non alkaline). Rinse well with fresh water removing any detergent residue paying particular attention to any areas that could retain residue. Care should be taken to avoid excessive amounts of water remaining in contact with your stainless steel. Abrasive materials or strong detergents must never be used to clean your stainless steel.

"The Product" means stainless steel or aluminium products including but not limited to fencing and balustrade systems.

"the Supplier" means Everton Australia Pty Ltd Trading as Protector Premium

"the Warranty Period" means twelve (12) months from the Date of Purchase;

"the Prescribed Purpose" means for use solely and exclusively for the intended purpose as outlined in the products installation instructions.

Maintenance

Like all surfaces, stainless steel and aluminium requires cleaning to remove dirt and grime to keep it in pristine condition. The level of cleaning and maintenance required depends primarily on the environment, e.g. coastal situations, the surfaces will require regular washing to retain their good looks and prevent tea staining.

Environment	Posts/Mini-Posts	
Seafront	Monthly	
Coastal (within 5km of the coast)	6-12 months	
Urban	6-12 months	
Suburban Rural	As required to maintain appearance	

NOTE: Harsh abrasives should never be used on any polished metal surface.

For further information regarding care and maintenance refer to our website.

